





SEIKO

QUARTZ

Cal. 2A32A

**PARTS
CATALOGUE**

Cal. 2A32A



012 005	012 006	012 007	012 008	012 015	032 001	032 002
032 003	032 004	032 005	032 006	032 007	032 008	2/1

Cal. 2A32A

Characteristics

Casing diameter : ϕ 20.0 mm
 Maximum height : 2.7 mm w'out battery
 Jewels : 2 j
 Frequency of quartz crystal oscillator : 32,768 Hz (Hz=Hertz Cycles per second)
 Driving system : Step motor (2 poles)
 Regulation system : Trimmer condenser
 Train wheel setting
 Calendar (Date)
 Instant setting device for date calendar
 Battery life indicator

PART NO.	PART NAME	PART NO.	PART NAME
125 350	Train wheel bridge	012 007	Date jumper screw (B)
231 350	Third wheel & pinion	012 008	Date driving wheel screw
☆241 352 } ☆241 355 }	Fourth wheel & pinion	012 015	Case screw
☆241 357 }		032 001	Tube for train wheel bridge (A)
261 350	Minute wheel	032 002	Tube for train wheel bridge (B)
☆270 351 } ☆270 355 }	Center minute wheel	032 003	Tube for circuit block cover screw (A)
☆271 351 } ☆271 363 }		032 004	Tube for circuit block cover screw (B)
282 351	Clutch wheel	032 005	Tube for circuit block cover screw (C)
☆354 073 } ☆354 351 }	Winding stem	032 006	Tube for setting lever spring screw
383 350		Setting lever	032 007
384 350	Yoke	032 008	Tube for date jumper screw (B)
388 350	Setting lever spring	☆ SEIKO TR621SW	Silver (II) oxide battery
391 350	Train wheel setting lever	☆ Maxell SR621SW	Silver oxide battery
426 350	Train wheel bridge support		
436 350	Lower end-piece for third wheel		
486 350	Clutch wheel guard		
491 141	Dial washer		
556 351	Date finger		
701 350	Fifth wheel & pinion		
☆801 126 } ☆801 127 }	Date dial		
802 350		Date driving wheel	
808 353	Date dial guard		
810 350	Date jumper		
817 350	Intermediate date wheel		
☆884 144 } ☆884 290 }	Holding ring for dial		
4000 350		Circuit block	
4002 350	Coil block		
4146 350	Step rotor		
4219 350	Battery connection insulator		
4225 350	Battery clamp		
4239 350	Rotor stator		
4270 350	Battery connection (-)		
4398 350	Crystal oscillator spacer		
4408 351	Circuit block spacer		
4457 368	Circuit block cover		
011 334	Upper hole jewel for step rotor		
011 334	Lower hole jewel for step rotor		
012 005	Train wheel bridge screw		
012 005	Circuit block cover screw		
012 005	Setting lever spring screw		
012 006	Date jumper screw (A)		








☆ ⇨ Please see remarks on the reverse page.
 Part numbers in light letters are not shown in photos.

Cal. 2A32A

Remarks :

Fourth wheel & pinion, Center minute wheel, Hour wheel

There are some different types as specified below.
Combination :

Type	Fourth wheel & pinion	Center minute wheel	Hour wheel
a	 ☆241 355	 ☆270 355	 ☆271 363
b	 ☆241 357	 ☆270 351	 ☆271 351
* c	 ☆241 352		

* As of this printing the type a combination is not used. However it may be employed in the future with certain case designs.

Winding stem

☆354 073 }Refer to the photograph on the front page.
 ☆354 351 }

If the combination of the winding stem and case is unknown, check the case number and refer to "SEIKO Quartz Casing Parts Catalogue" to choose a corresponding winding stem.

Date dial

- ☆801 126 (Black figures on white background).....Used when both the crown and the calendar frame are located at 3 o'clock position.
- ☆801 127 (White figures on black background).....Used when the crown are located at 3 o'clock position and the calendar frame at 6 o'clock position.

If any other type of date dial is required, specify ① Cal. No. ② The crown position ③ The calendar frame position and ④ Dial No.

Holding ring for dial

☆884 144 } The type of a holding ring for dial is determined based on the design of cases.
 ☆884 290 } If there is different from the photograph, check the case number and refer to "SEIKO Quartz Casing Parts Catalogue" to choose a corresponding holding ring for dial.

Battery

☆SEIKO TR621SW.....The substitutive battery might be added to the applied battery in the future. In that case, please refer to separate "BATTERY LIST FOR SEIKO QUARTZ WATCHES".
 Note that SEIKO battery is marked with "SEIZAIKEN" on its (+) side.